



Setup instructions Play Tipi

Supply: 1 tarp (100 % cotton, impregnated)
Tent pegs
Tent bag
Depending on order:
6 tent poles (bamboo for the cover)
2 tent poles (bamboo for the smoke flaps)

1. Look for a suited place, like a meadow. Unpack the tent – it is already prepared for setup because the poles are connected with the tarp.
2. Put the tent vertical with the tent poles. It is recommended that a second person holds the construction. Separate the tent poles and place them in a circle with equal space in between.
3. Tighten the tent pegs and loops; arrange tent poles again to tighten the tarp.
4. Put the two single tent poles in the corners of the smoke outlets



Care Instructions – for a long life Play Tipi

After setup or a long-term usage tighten the tent and fix the pegs from time to time.

1. Air regularly. If tent stands for long time, loosen tarp from the ground and dry. Loops should not touch the ground. Keep the meadow short around the tipi.
2. If the tipi is used the whole summer or half a year it should be moved from time to time to preserve the meadow.
3. Dismount the tipi during dry weather or dry thoroughly afterwards. Only store when completely dry!
4. Clean and impregnate tarp again after two years with a common impregnating agent. Special cleaner is recommended.

Keep away from fire! This tent is not suitable for fire!

Workshop:
TLG Geo Gewerbepark
Halsbrücker Straße 31 a
09599 Freiberg
UST-ID: DE141146157

Office:
Gartenstraße 4
09619 Sayda

Tel: 0049 3731 213580
Fax: 0049 3731 213582
<http://www.halang.de>
E-Mail: info@halang.de