



Setup instructions for Viking Tent

Congratulations on your new tent.

Depending on the volume of your order the wooden frame is included in the supply or has to be manufactured by you in self-work.

Instructions:

Look for a suitable clean and even surface.

Put the boards (which later form the bevels) on the ground that the holes for the ridgepole are one above the other.

Place the boards in front and in the back far away enough that the ridgepole fits between them.

Now insert the ridgepole in the holes and wedge it a little bit.

Afterwards insert the other two poles at the lower end in the holes and wedge it. Put the soffit (board) on one side of the wooden linkage and wedge it.

Now spread the tarpaulin over the lying construction. That way you don't have to throw the tarpaulin over the construction when it stands.

If the ground floor is wet I recommend setting up the wooden linkage first and then draw up the tarpaulin. Like this it will remain clean.

Now you and may be your assistant take an end of the ridgepole. It has to hoist so far till the soffit can be pushed into the hole of the third pole and wedge it.

Following check all wedges and make them firmer.

Finally you can stretch and fasten the tarpaulin.

Please note!

1. After building up the tent you should check the bracing regularly.
2. Always air well.
3. If possible strike the tent dryly or dry well. Only store the tent well packed and in a dry place.
4. The material for the tarp is 100% natural cotton. You can wash or clean it easily.
After cleaning or washing please impregnate the tent with common impregnant.

Have fun with your Viking Tent!

Workshop:
TLG Geo Gewerbepark
Halsbrücker Straße 31 a
09599 Freiberg
UST-ID: DE141146157

Office:
Gartenstraße 4
09619 Sayda

Tel: 0049 3731 213580
Fax: 0049 3731 213582
<http://www.halang.de>
E-Mail: info@halang.de

